



FRIEND-CHIP,
STUDIO ELECTRONICS

DMX64 Intallation of Modules


The DMX64 frame must be totally removed from the 19" rack.

! Disconnect powersupply before installation !

Remove all screws on top and bottom.

Slowly move the frame which carries the modules out of the frontpart.

Display and keys are connected at the right side.



Some modules may have more or less pins, than the sockets on the matrix board.
Modules must be installed that pins match at the top. Pins may not match at the bottom of a socket or module.
